

Godefa



Need help?

No problem. Email our after sales customer service at

service@godefa.com

Product picture and description:



- 1 198° Fisheye Lens
- 2 0.63x Wide angle Lens
- 3 15x Macro Lens
- 4 18x telephoto Lens
- 5 Clip for telephoto lens
- 6 CPL filter lens
- 7 6 kaleidoscope lens
- 8 Camera remote control
- 9 Tripod
- 10 Clip for other 5 lenses

WIDE ANGLE LENS+ MACRO LENS KIT BREAKDOWN DRAWING



Wide+Macro
Detachable Lens

How to use tripod:



How to install camera lens:

- Step1** Put the clip on your phone, make sure phone camera lies in the center of the clip
- Step2** Screw the lens in



How to install camera lens:

Step1 Adjust the clip based on the position of phone camera



Step2 Put the clip on your phone, make sure phone camera lies in the center of the clip, tighten the screw
Note: For dual camera phone, clip the lens over main camera



Step3 Screw the telephoto lens into the clip



Step4 Shoot object 10ft away, adjust focus ring to get clear picture



Attach the eyepiece to the telephoto lens, used as monocular



Features:



18X telephoto lens: allow you capture the scenery far away without compromising image quality, it has minimum focus distance of 10 ft



0.63X wide angle lens: allow you capture more landscape in a single picture, it is great for cityscape and large group photos



15X macro lens: designed for photographing small subjects at very close distances, usually 1-3 inch, photographing insects, plants and small product, allow you see details in the photo



198° fisheye lens: show a distorted, spherical view of the world, it is also a extra-wide lens with up to a 198 degree of view



CPL filter lens: used to remove unwanted reflection from non metallic surfaces such as glass or water to enhance color saturation. For example, remove the reflection from water surface to capture the fish or other objects in the water



6 kaleidoscope lens: take colorful picture like a kaleidoscope, show 6 overlapping vision

Precautions for use:



Fragile Product



Keep Dry



Caution Dust



No Phone Case

Frequently asked questions

Q: Why there is no macro lens or missed one lens?

A: When you receive the lens, wide angle and macro lens are screwed together, it is wide angle lens function. Unscrew wide angle lens from lens kit, it is macro lens function.

Q: Is the lens clip going to damage mobile phone?

A: Please be rest assured there is EVA rubber on lens clip, it provides protection for your phone, not damaging.

Q: About clarity ?

A: Since the lens belong to special good effect, the photo surroundings will be blurred which can not keep the original cellphone camera definition.

Q: Why the flash light stopped working when lens is used ?

A: This is because lens diameter is bigger than mobile phone camera. When you put lens on mobile phone camera, it will block flash light. So it can not work.