


# **MODEL #: ZK420**

## **Instruction Manual**



**Before operating this scale, please read the instruction manual and keep it handy for future reference.**

## LCD DISPLAY



## SPECIFICATIONS

- 1 Capacity: 1 g - 6000 g
- 2 Division: 0.5 g / 0.01 oz / 0.001 lb
- 3 UNIT: g / oz / ml / lb / lb:oz
- 4 Power: 3 x AAA batteries (DC 4.5V), not included
- 5 Operating temperature: 10 - 40°C / 50 - 104°F
- 6 Storage temperature: -10 - 50°C / 14 - 122°F
- 7 Humidity: 90%RH
- 8 Low battery indicator: "Lo"
- 9 Max weight exceeded error: "Err"
- 10 Instability detected: "UnSt"

## INDICATORS

- 1 When the LCD displays "Lo" and powers off, please install new batteries.
- 2 When the weight on the scale exceeds 6,000 g, "Err" will display on the screen. Remove any items from the scale's platform to avoid damage.
- 3 When movement or instability is detected, "UnSt" will display. Ensure items are placed on the center of the scale's weighing platform, and that the scale is on a level platform.

## **OPERATING THE SCALE**

- Install 3 new AAA batteries.
- Place the scale on a flat even surface.
- Press the Power/Tare button to turn on the scale.
- Press the Unit button to change the unit of measurement between: g / oz / ml / lb / lb:oz
- Tare: The Tare button can be used to zero the weight of an empty container, plate, cup or bowl, so that the scale only measures what is placed inside the container. The Tare button can also be used to determine Individual weights of items added within the same measuring session (i.e., 5 grams of this, 7 grams of that, etc). To Tare a measurement, place the empty container on the scale and press the Tare button. The scale will reset to zero and display the TARE symbol on the LCD. Then add your ingredients. [Note: due to a programming quirk, the TARE symbol will not display on the LCD if the container's weight is less than 100 g, but the Tare function will still work as described.]
- To deactivate TARE, press the Tare button again, or turn off the scale by pressing and holding the Power/Tare button.

**Note:** This scale measure to the nearest 0.5 g / 0.01 oz. In the case of grams (g), the scale will round to the nearest half gram as follows:

- For X.0, X.1, X.2, the scale will round to X.0 grams
- For X.3, X.4, X.5, X.6, X.7, the scale will round to X.5 grams
- For X.8, X.9, the scale will round to X+1.0 grams

---

## **CARE INSTRUCTIONS**

---

- 1** Always ensure the scale is stored and operated at room temperature and on a stable flat surface.
- 2** Gently place all items on the scale's weighing platform. Never drop an item on the scale. Never leave an object on the scale for an extended period of time.
- 3** Avoid placing the scale near cell phones or other devices that can cause electromagnetic interference.
- 4** Store the scale in a clean dry location. Exposure to dust, dirt and moisture from humidity can cause inaccuracy or malfunction.
- 5** Do not mix old and new batteries.
- 6** Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc.) batteries.
- 7** Remove the batteries if the scale will not be used for an extended period of time.
- 8** This scale is intended for indoor use only. Do not operate or store the scale in extreme temperatures.
- 9** This product is not a toy and should be kept away from children.
- 10** Do not attempt to disassemble this scale. Doing so will void the warranty.

---

## **WARRANTY**

---

Your Ozeri Scale is warranted to the original owner for 1 year from the date of purchase against defects in material and workmanship under normal use and service. Should your scale prove defective within 1 year from the date of purchase, return the defective part or unit, freight prepaid along with the original receipt and an explanation of the claim to "Ozeri Scale." Please pack your scale carefully to avoid damages in transit. Under this warranty, Ozeri will repair or replace any parts found to be defective due to a manufacturer's defect. This warranty extends only to personal use and does not extend to any product that has been used for commercial use, rental use, or use which is not intended. There are no warranties other than that expressly set forth herein. This warranty is not transferable.

**Ozeri Scale Customer Service:**

Phone: 1-877-299-1296

Email: [support@ozeri.com](mailto:support@ozeri.com)